








## Installation instruction




3




OK

4



OK

5



~~OK~~

**tyco**  
 Thermal Controls

**European Headquarters**  
 Tyco Thermal Controls  
 Romeinse Straat 14  
 3001 Leuven  
 Belgium  
 Tel. (32) 16 213 511  
 Fax (32) 16 213 610

[www.tycothermal.com](http://www.tycothermal.com)

© 2008 Tyco Thermal Controls INST-304 Rev.0 01/09 Printed in Belgium on recycled paper